

ST-01 STD-01 ST-11 STD-11	Плата ST-01.771 X3	
	PASS B	7
	PASS A	6
	COMMON	5
	X2	
	UNLOCK B	4
	UNLOCK A	2
	GND	1

CT/L14.1	
XT1	IN
1	IN1 (IN3)
2	GND
3	IN2 (IN4)
XT6(8) OUT1(3)	
1	NO1 (NO3)
2	C1 (C3)
3	NC1 (NC3)
XT7(9) OUT2(4)	
1	NO2 (NO4)
2	C2 (C4)
3	NC2 (NC4)

ST-02 STD-02	DIN-рейка	
	PASS B	24
	PASS A	23
	COMMON	22
	GND	8

CT/L14.1	
XT1	IN
1	IN1 (IN3)
2	GND
3	IN2 (IN4)
XT6(8) OUT1(3)	
1	NO1 (NO3)
2	C1 (C3)
3	NC1 (NC3)
XT7(9) OUT2(4)	
1	NO2 (NO4)
2	C2 (C4)
3	NC2 (NC4)

TTR-08A TTD-08A	Клеммная колодка XS1	
	PASS B	14
	PASS A	13
	COMMON	12
	UNLOCK B	8
	UNLOCK A	6
	GND	5

CT/L14.1	
XT1	IN
1	IN1 (IN3)
2	GND
3	IN2 (IN4)
XT6(8) OUT1(3)	
1	NO1 (NO3)
2	C1 (C3)
3	NC1 (NC3)
XT7(9) OUT2(4)	
1	NO2 (NO4)
2	C2 (C4)
3	NC2 (NC4)

TTR-07.1	Плата CLB XT1	
	PASS B	7H
	PASS A	6H
	COMMON	5H
	GND	6L

CT/L14.1	
XT1	IN
1	IN1 (IN3)
2	GND
3	IN2 (IN4)
XT6(8) OUT1(3)	
1	NO1 (NO3)
2	C1 (C3)
3	NC1 (NC3)
XT7(9) OUT2(4)	
1	NO2 (NO4)
2	C2 (C4)
3	NC2 (NC4)

TTR-04.1 TTR-04CW TTD-03.1 TTD-03.2 T-5	Плата CLB XT1	
	PASS B	7H
	PASS A	6H
	COMMON	5H
	UNLOCK B	6L
	UNLOCK A	4L
	GND	3L

CT/L14.1	
XT1	IN
1	IN1 (IN3)
2	GND
3	IN2 (IN4)
XT6(8) OUT1(3)	
1	NO1 (NO3)
2	C1 (C3)
3	NC1 (NC3)
XT7(9) OUT2(4)	
1	NO2 (NO4)
2	C2 (C4)
3	NC2 (NC4)

RTD-03S	Блок управления Разъем ACS	
	PASS R2	10
	PASS L2	9
	PASS R1	7
	PASS L1	6
	GND	5
	LEFT	3
	RIGHT	1

CT/L14.1	
XT1	IN
1	IN1 (IN3)
2	GND
3	IN2 (IN4)
XT6(8) OUT1(3)	
1	NO1 (NO3)
2	C1 (C3)
3	NC1 (NC3)
XT7(9) OUT2(4)	
1	NO2 (NO4)
2	C2 (C4)
3	NC2 (NC4)

RTD-15 RTD-16	DIN-рейка	
	PASS B	XP22
	PASS A	XP21
	COMMON	XP20
	UNLOCK B	XP11
	UNLOCK A	XP9
	GND	XP7

CT/L14.1	
XT1	IN
1	IN1 (IN3)
2	GND
3	IN2 (IN4)
XT6(8) OUT1(3)	
1	NO1 (NO3)
2	C1 (C3)
3	NC1 (NC3)
XT7(9) OUT2(4)	
1	NO2 (NO4)
2	C2 (C4)
3	NC2 (NC4)

TTD-10A	Клеммная колодка XTU2	
	PASS B	14
	PASS A	13
	COMMON	12
	GND	5

CT/L14.1	
XT1	IN
1	IN1 (IN3)
2	GND
3	IN2 (IN4)
XT6(8) OUT1(3)	
1	NO1 (NO3)
2	C1 (C3)
3	NC1 (NC3)
XT7(9) OUT2(4)	
1	NO2 (NO4)
2	C2 (C4)
3	NC2 (NC4)